



### Regulations

Maximum height of take-off point = 750 mm above waterline  
 Minimum height of take-off point = 500 mm above waterline.  
 Backstroke handle should be in line with pool edge.

### When Ordering

Specify distance from Water line to Concourse level where Block is to be fixed.  
 Provide sketch showing dimensions of concourse.

### Installation

Standard installation is with stainless steel Dynaset M10 fasteners which require 12 mm holes. Location holes should not be drilled before the blocks arrive on site. Full information is provided on the Techlink part of our site at [www.anti.to](http://www.anti.to)

### Materials

The Fina Block is made from Fibre Reinforced Plastics.

	<b>TITLE</b> <b>SUPER START BLOCK</b>	<b>SCALE</b> <b>1:10</b>	<b>DATE</b> <b>04.04.99</b>	<b>DRAWING N°</b> <b>AWE 00063a</b>	<b>NOTES</b> New platform 13.09.00 Drawing updated 06.06.02 Revised 16.10.02
--	--	-----------------------------	--------------------------------	--	---